BPW Axle, Steer Axle and/or Airbag Suspension First Service Checklist and ECO Plus and ECO Plus 3 Hub Unit Extended Warranty Application*



	First Service Authorisation Number -
NB - ECO Plus Hub Unit extended guarantee is not accepted without valid VIN Number *	

First Service to be performed between the first 1,000km to 5,000km that the vehicle is in operation.

Please return completed checklist to BPW Transpec Ptv Ltd for warranty registration.

	Service Requirement				Tick	Comments	
ဖွ	Check operation of airbag pneumatic system and that it is piped correctly. Also check height control valve linkage arrangement. (p. 55 of Operator's Manual)			HUN	Comments		
Suspensions	Check ride height on axle fitted with height control valve. Re-set if necessary to manufacturer's recommendation. Ensure trailer air supply is connected and brakes are released.						
nspe	Retighten spring eye bolts to specified torques -		W36) = 650 Nm (480 ft/lbs) W46) = 1000 Nm (740 ft/lbs)				
	Retighten U-bolt nuts to specified torq	ue -	M24 = 650 Nm (480 ft/lbs)				
rbag	Retighten shock absorber fasteners to specified torque -		M24 = 425 Nm (315 ft/lbs)				
BPW Airbag	Retighten airbag fasteners to specified torque -		M12 = 66 Nm (49 ft/lbs) M16 = 230 Nm (170 ft/lbs)				
A	Check alignment plates are welded to	Check alignment plates are welded to seats (if fitted).					
В	Check for air leaks and rectify if necessary.						
-	Remove hubcap and re-adjust bearings to the required specifications as shown on page 26 of the Operator's Manual. Replace hubcap o'ring		n				
Axles	Check brake adjustment. Adjust if necessary (including auto slack operation) (p.68-71)		-71)				
Α×	Visually check for loose fasteners. Re	Visually check for loose fasteners. Re-tighten if necessary (including camshaft bolts)					
PW.	With disc brake axles: Check that the brake caliper brake adjuster cap is in place. Fit new cap if required.						
BF	With disc and drum brake axles: Check that the lower plastic vent plugs have been removed from the BPW brake boosters. Remove vent plug if necessary.			ed from			
	Check / retighten torque of track rod c		M12 = 86 Nm (63 ft/lbs) (A)				
	Check / retighten torque of track rod n	` '	M24 = 550 Nm (406 ft/lbs) (B)				
W Steer Axles	Check / retighten torque of king pin cover (C) clate bolts & king pin booster bracket cover clate bolts A M16-10.9 = 230 Nm (170 ft/lbs)(C) M16-8.8 = 163 Nm (120 ft/lbs) (C) M14 = 148 Nm (109 ft/lbs) (C) M10-10.9 = 53Nm (39 ft/lbs)(C) M10-8.8 = 38Nm (28 ft/lbs) (C) Item C is dependant on configuration) (C)) C)			
BPW Ax	C		configuration				
Date : Trailer Manufacturer		Trailer Manufacturer	:	Trailer Owner:			
Trailer Registration Number : Kilometres Travelled :				Order / Job Card	r / Card No. :		
BPW Suspension Serial No.: Trailer Inservice Date: As per VIN Pl				Service rmed by : Company Name:			
Trailer Type: Pig Trailer Dog Trailer Semi Trailer Trailer Curtain Sider Tanker Low Loader Tipper Other				of Axles	Axle Se	erial Numbers:	